

Cleaning and Cleanliness Measurement of Additive Manufactured Parts

Roger W. Welker

Sr. Contamination Control Engineer



Jacobs ESSSA/Marshall Space Flight Center

Mark A. Mitchell

Project Lead

EM50

NASA/Marshall Space Flight Center





Cleaning and Cleanliness Measurement of Additive Manufactured Parts

- **Rationale for technical approach:**
 - Alloys for liquid fuel rocket engines are expected to be relatively hard, high melting point, corrosion and ultrasonic cavitation erosion resistant alloys: Ultrasonic [u/s] immersion cleaning should be a viable method
 - Selective laser melting process avoids use of organic materials, like cutting fluids, mold release compounds, etc.: This makes aqueous [H₂O] based cleaning a viable candidate
 - Move toward an objective means of assessing cleanliness rather than visual inspection: turbidimetry of extracted contamination
 - Multiple u/s extraction [MUX] has been successfully used to develop cleaning processes for similar materials

Cleaning and Cleanliness Measurement of Additive Manufactured Parts



Current effort:

- Cleanliness measurements
 - u/s extraction in detergent/H₂O solution followed by turbidimetry
 - Turbidimetry of aqueous ultrasonic (u/s) extracts is a well accepted method for indirect cleanliness measurements of metal parts
 - All equipment needed for measurements is already available
- Cleaning methods development
 - Prior work shows Inconel 718 exhibits well behaved multiple ultrasonic extraction¹: Other alloys for liquid fuel engines expected to be the same
- Cleaning method candidates
 - H₂O: u/s immersion, spray, u/s immersion + spray
 - Solstice PF: u/s immersion/vapor degrease, u/s immersion/spray/vapor degrease

¹ JANNAF Liquid Propulsion Subcommittee and Advanced Materials Panel TIM, Huntsville, AL, 3 - 5 September 2014



Experimental Procedures

Turbidity measurements¹:

1. Clean 300 ml Berzelius (high form) beaker and fill w/ 250 ml filtered distilled water containing approximately 0.02 % by volume Joy detergent
2. Sonicate 1 minute in Branson 5810 u/s tank filled w/ room temp. water
3. Fill vial with water/detergent mixture,
u/s degas and measure turbidity in Hach – blank turbidity
4. Sonicate part for 1 minute.
5. Repeat step 3 – part turbidity
6. Subtract result 3 from result 5 to get net turbidity
increase due to contamination extracted from the part

¹ When water ultrasonic immersion cleaning experiments are done, the turbidity of the water detergent is measured before and after cleaning, as well as extracting the parts after cleaning

Equipment Used



**Working fluid: 250 ml
filtered distilled H₂O in 300
ml beaker, 200 ppm (0.02%)
Joy detergent, centered in
tank, 1.0 minute extraction**




**Branson 8510 5.5 gallon (22
liter)
42 kHz, 250 watt (nominal –
not measured)
Coupling fluid: room temp
(22°C) tap H₂O, degassed 5
minutes**



**Hach 2100N Ratio
Turbidimeter
0.001 NTU resolution (gage
capability for this test not
yet determined)**


Multiple Extractions

A Well Behaved Multiple Ultrasonic Extraction



Multiple Extractions

Three different types of ultrasonic cleanability curves



a) Well behaved

b) Erosion sensitive


- *Ultrasonic cleaning must be done with care*
- *Ultrasonic extraction for verification still useful*

c) Extremely erosion sensitive

- *Neither ultrasonic cleaning nor ultrasonic extraction are suitable*

Multiple Extractions



Using the multiple ultrasonic extraction cleanliness curve to assess cleanliness, cleanability and cleaner performance



The Test Specimen

Surface area = 2831.6 mm^2

Smallest holes are approximately 0.5 mm in diameter



Cleaning Test Matrix



Test	Description	Purpose
1	5 parts MUX	1. Determine the variability of u/s cleanability and cleanliness level
		2. Determine a preliminary u/s immersion cleaning process time
2	5 parts u/s cleaned in detergent/H ₂ O solution	Determine preliminary cleanliness capability for US immersion cleaning in detergent/H ₂ O solution
3	5 parts spray cleaned using with DI/H ₂ O only	Measure spray cleaning process capability
4	5 parts US washed in detergent/H ₂ O solution followed by Millipore FilterJet spray rinse with H ₂ O only.	1. Measure u/s wash + spray rinse process.
		2. Does adding spray rinse improve cleanliness?
5	4 parts 3 minute u/s wash + vapor degrease	Measure Solstice PF performance in u/s vapor degreaser
6	5 parts 3 min u/s wash + 1 minute cold spray rinse + vapor degrease	Does adding cold Solstice PF spray rinse improve cleanliness?
7 - 11	2 parts from test 2 - 6 be cryo-shocked. 2 other parts from test 2 - 6 to be measured as control	Does cryo-shock degrade cleanliness of cleaned parts?



Additional Tests

- Parts were weighed before and after cleaning to supplement turbidity measurements
 - Parts highly variable in appearance: document by mass variability
 - Needed data for drying tests
- Parts were reused after cleaning for drying experiments
 - Compressed air blow-off plus room temperature air dry overnight
 - Blow-off plus oven baking
 - Blow-off plus vacuum oven baking
 - Blow-off plus solvent displacement drying

Variation in Appearance and Weight



Weights vary from 31.3622 grams
to 33.2450 grams


Experimental Procedures

- Parts are handled with washed, dry gloves or clean dry forceps (no bare hands) for all tests
- Condition the parts to room temperature before weighing
- Parts weighed with calibrated electronic balance to ± 0.0001 gm



Multiple Ultrasonic Extraction Results


- A single part was subject to multiple u/s extraction (MUX) that produced an anomalous result
- Part was tested immediately after receipt, 2-9-2015
- No additional parts were tested until 3/26/2015 (wait for task order release)
- Anomalous result:
 - Initial cleanliness = 7.72 NTU
 - Asymptote = 0.65 NTU



Multiple Ultrasonic Extraction Results

- 5 additional parts were later tested to determine MUX curve

Part No.	Test Date	Initial NTU	Asym. NTU
21	3/26	4.21	0.83
28	3/30	2.46	0.75
9	4/01	2.65	0.54
1	4/02	2.70	0.49
4	4/03	2.49	0.56



- Initial cleanliness significantly different from no. 8, but consistent within the group. Asymptote the same for all 6 MUX.
- Predict 3 minute ultrasonic cleaning time



3 Minute Detergent/H₂O Ultrasonic Cleaning

Part No.	3 Minute Clean			Measurement		
	Blank, NTU	after 3 min, NTU	Net ¹ , NTU	Blank, NTU	Measure, NTU	Net ² , NTU
20	0.23	3.41	3.18	0.23	1.05	0.82
5	0.16	2.39	2.23	0.29	1.01	0.72
26	0.36	5.33	4.97	0.17	1.12	0.95
11	0.52	2.81	2.29	0.23	0.91	0.68
13	0.30	4.18	3.88	0.26	0.79	0.53

¹ Left in the beaker after cleaning.
After 3 min. clean, the net NTU should be comparable to the sum of the net NTU in the MUX at 1 + 2 + 3 min.

² After 1 min. extraction
The measured cleanliness should be comparable to the asymptotic cleanliness from the MUX



3 Minute Detergent/H₂O Ultrasonic Cleaning

Statistical analysis:

After 3 minute clean, the net NTU should be comparable to the sum of the net NTU in the MUX at 1 + 2 + 3 minutes

	3 min. clean, NTU	MUX (1+2+3), NTU
Mean	3.31	4.59
St. Dev.	1.152	0.855
N	5	5

P =0.0843
Not significantly different


The measured cleanliness should be comparable to the asymptotic cleanliness from the MUX

	After 3 min. u/s clean	Asymptote, MUX
Mean	0.74	0.62
St. Dev.	0.157	0.156
N	5	5

P =0.143
Not significantly different

3 Minute High Velocity H₂O Spray

- Millipore Filterjet w/ 5 μm filter at 50 ± 3 psig produces a finely collimated solid stream of liquid flowing at approximately 17.5 m/sec.
- **Parts were hand held and sprayed for 3 minutes with filtered distilled H₂O (no detergent)**
- **Parts were not allowed to dry, but were immediately extracted and turbidity measured**



3 Minute High Velocity H₂O Spray

Results:

Part No.	Blank, NTU	Measure, NTU	Net, NTU
27	0.46	1.88	1.42
7	0.09	1.48	1.39
2	0.20	2.27	2.07
23	0.19	2.27	2.08
18	0.23	0.81	0.58

Statistical analysis:

	After 3 min. spray clean	Asymptote, MUX
Mean	1.51	0.62
St. Dev.	0.616	0.156
N	5	5

P =0.0153
Significantly different

Conclusion: high velocity spray clean alone does not reach the asymptote and should not be considered a stand-alone cleaning process



3 Min. Ultrasonic in Detergent/H₂O + 1 Min. H₂O Spray

Results:

Part No.	After 3 Min. u/s Clean			After 1 Min. Spray		
	Blank, NTU	after 3 min, NTU	Net ¹ , NTU	Blank, NTU	Measure, NTU	Net ² , NTU
24	0.31	1.32	1.01	0.24	0.43	0.20
17	0.08	1.88	1.80	0.35	0.89	0.54
6	0.25	2.32	2.07	0.30	0.63	0.33
10	0.26	2.14	1.88	0.21	0.90	0.68
12	0.27	3.60	3.34	0.27	0.68	0.41

¹ Left in the beaker after 3 min. clean ² After 1 min. extraction

- After 3 u/s min. clean, the net NTU should be comparable to the nets of previous 3 min. u/s clean.
- Measurement after spray rinse should compare to MUX asymptote
- Does spray rinse improve results of u/s wash alone?




3 Min. Ultrasonic in Detergent/H₂O + 1 Min. H₂O Spray

Statistical analysis:

	After 3 min. u/s clean	Prior 3 min. u/s clean
Mean	2.02	3.31
St. Dev.	0.839	1.15
N	5	5

P =0.0773
Not significantly different

- Conclusion: Adding spray
rinse improves cleanliness
vs. 3 min. u/s clean alone**



	After 3 min. u/s + 1 min. spray	Asymptote, MUX
Mean	0.43	0.62
St. Dev.	0.189	0.156
N	5	5

P =0.1212
Not significantly different

	After 3 min. u/s + 1 min. spray	After 3 min. u/s clean
Mean	0.43	0.74
St. Dev.	0.189	0.157
N	5	5

P =0.0225, significantly different

3 Min. Ultrasonic Vapor Degrease in Solstice PF



- Solstice PF boils @ 19 °C (66 °F)
- Auxiliary cooling coil added to u/s tank to chill solvent below boiling point to ~12 °C (~54 °F)
- Two cleaning processes tested:
 - u/s clean for 3 min., then hold in vapor zone until condensation stops
 - u/s clean for 3 min., spray rinse with cold Solstice PF for 1 minute, then hold in vapor zone until condensation stops

3 Min. Ultrasonic Vapor Degrease in Solstice PF



u/s clean for 3 min., then hold in vapor zone until condensation stops

Results:

Part No.	Blank, NTU	Measure, NTU	Net, NTU
16	0.541	3.81	3.269
14	0.168	3.38	3.212
15	0.233	3.35	3.117
30	0.186	3.73	3.544

Statistical analysis:

	After 3 min. u/s + 1 min. spray	Asymptote, MUX
Mean	3.29	0.62
St. Dev.	0.183	0.156
N	4	5

P =0.0001
**Extremely significantly
different**

3 Min Ultrasonic Vapor Degrease + 1 min Spray Rinse in Solstice PF



Results:

Part No.	Blank, NTU	Measure, NTU	Net, NTU
29	0.29	3.91	3.62
25	0.203	2.71	2.50
19	0.326	2.38	2.05
3	0.23	1.95	1.72
22	0.309	3.46	3.15

Statistical analysis:

	After 3 min. u/s + 1 min. spray	Asymptote, MUX
Mean	2.61	0.62
St. Dev.	0.779	0.156
N	5	5


P =0.0001, Extremely significantly different

	After 3 min. u/s + 1 min. spray	After 3 min. u/s clean
Mean	2.61	3.29
St. Dev.	0.779	0.183
N	5	4

P =0.1355, Not significantly different


Graphic Representation of Cleaning Results

- MUX shown as mean, mean plus 1 st.dev. and mean minus 1 st.dev. versus extraction number.
- Clean process shown as horizontal lines of mean values to show intercept versus initial cleanliness and asymptote of MUX



Cleaning Results versus Mass Loss

- Mass loss is negatively correlated with turbidity after cleaning (i.e., if little cleaning is done, most of the mass is left on the part and turbidity is high)





Further Discussion – H₂O Based Cleaning

- H₂O based cleaning, based on residual turbidity after cleaning is in the order:

Best: Detergent/H₂O u/s wash + high velocity spray rinse

Good: Detergent/H₂O u/s wash

Poor: High velocity H₂O spray clean

- Detergent/H₂O u/s wash + spray rinse is significantly better than u/s wash alone (no rinse): This is not unexpected.

MUX shows that cavitation erosion occurs, though not catastrophic

Not rinsing with high velocity spray after u/s clean leaves the erosion debris on the parts, increasing measured turbidity after cleaning

This effect is seen as a lower net NTU for u/s + spray than the MUX asymptote

Further Discussion – Solstice PF

- Note similarity of turbidity of 3 min. u/s degrease in Solstice PF and 3 min. u/s degrease + 1 min. spray rinse in Solstice PF versus 1st extraction in MUX

	MUX, 1 st Extract	Solstice Clean
Mean	2.90	2.91
St. Dev.	0.738	0.665
N	5	9

P =0.9838
Not statistically different

- This suggests very little cleaning is accomplished in u/s or u/s plus spray in the Solstice PF in the vapor degreaser.
- This result is not unexpected, as very low boiling point, low surface tension solvents don't perform well in u/s cleaning of particles



Drying Experiments

- H_2O based cleaning introduces the problem of part drying
- Procedure:
 1. Weigh the parts to ± 0.0001 g (0.1 mg)
 2. Wet the parts with distilled water
 3. Blow off the parts, one at a time, with compressed air at 50 psig until sensibly dry
 - 3a. If heat dried, dry in the oven or vacuum oven
 - 3b. If heat dried, allow the parts to cool to room temperature before weighing
 - 3c. If using solvent displacement drying, blow dry the parts again and allow the parts to return to room temperature before weighing (solvent evaporation chills the parts)
 4. Weigh the parts to ± 0.0001 g (0.1 mg)
- For statistical analysis use a paired t-test (each part is weighed B4 and after)

Drying Experiments

- 50 psig Compressed Air Blow Off + room temperature over-night

	Dry Mass, g	After Blow-Off, g
Mean	32.4310	32.4334
St. Dev	0.6122	0.6124
N	21	21

P =0.0002, Extremely statistically significant

- Leaves an average 2.4 mg of water on the parts
- Not surprising, considering the fine-internal passageways in the part

Drying Experiments

- Blow-off plus 60 °C Convection Oven Dry

	Dry Mass, g	After 60 C Oven Dry, g
Mean	32.4310	32.4315
St. Dev	0.6122	0.6124
N	21	21

P =0.2498, Not statistically significant

- Blow-off plus 60 °C convection oven dry leaves an average of 0.5 mg of water on the parts.
- While not statistically significant on average, 7 of the 21 parts showed incomplete drying, with an average of 3.8 mg per part.

Drying Experiments

- 60 °C, Vacuum Oven, 25" Hg, No Preheat, Rapid Vacuum

	Dry Mass, g	After Blow-Off, g
Mean	32.4310	32.4319
St. Dev	0.6122	0.6125
N	21	21

P =0.1712, Not statistically significant

- Using the vacuum oven without preheating the parts and without controlling the rate the vacuum is applied leaves an average 0.9 mg of water on the parts
- This is caused by too rapid application of vacuum to a water wet part that has not been preheated, causing water to freeze in narrow internal passages.

Drying Experiments

- 60 °C, Vacuum Oven, 25 “ Hg, Preheat 10 min., Gradual Vacuum

	Dry Mass, g	After Blow-Off, g
Mean	32.4310	32.4309
St. Dev	0.6122	0.6127
N	21	21

P =0.4727, Not statistically significant

- Preheating the parts on a 60 °C surface and gradually reduces the vacuum dries the parts. The difference in mass, 0.1 mg, is within the measurement tolerance of the balance.



Cryo-shock Experiments

Procedure:

1. Prepare parts
 1. Select 4 parts from each test clean procedure group
 2. Measure turbidity in detergent H₂O solution
 3. Rinse with EtOH to remove detergent and solvent dry, oven bake @ 60 °C for 30 min.
 4. Cool to room temp. in desiccator and weigh
2. Select 2 parts from each test clean procedure group and immerse in LN₂ until boiling stops
3. Measure turbidity and reweigh all 4 parts
4. Determine if there is a difference between cryo-shocked parts and control parts that were not cryo-shocked

Cryo-shock Experiments

Results:

- 20 parts tested: 10 cryo-shock treatment and 10 handling controls
- No significant difference between cryo-shocked and not cryo-shocked (control) parts.

Statistical analysis (delta turbidity)

	Control	Cryo-shock
Mean	0.327	0.271
St. Dev.	0.239	0.278
N	10	10

P =0.766, Not significantly different

LN2 cryo-shock does not have a significant effect on part cleanliness



Thank you for your attention!

Questions?

Interested in Collaborating on Cleaning Processes?
Please contact:

Mark Mitchell
NASA/MSFC/EM50
mark.a.mitchell@nasa.gov